

**SIA CP-01-2019**

**Security System Standard –  
Features for False Alarm Reduction  
(Revision of ANSI/SIA CP-01 -2014)**

**PUBLIC REVIEW DRAFT**



## Copyright Notice

Approval of an American National Standard requires verification by ANSI that the requirements for due process, consensus, and other criteria for approval have been met by the standards developer. Consensus is established when, in the judgment of the ANSI Board of Standards Review, substantial agreement has been reached by directly and materially affected interests. Substantial agreement means much more than a simple majority, but not necessarily unanimity. Consensus requires that all views and objections be considered and that effort be made toward their resolution.

The use of American National Standards is completely voluntary; their existence does not in any respect preclude anyone, whether he or she has approved the standards or not, from manufacturing, marketing, purchasing, or using products, processes, or procedures not conforming to the standards.

The American National Standards Institute does not develop standards and will in no circumstances give interpretation on any American National Standard in the name of the American National Standards Institute. Requests for interpretations should be addressed to the secretariat or sponsor whose name appears on the title page of this standard.

**CAUTION NOTICE:** This American National Standard may be revised or withdrawn at any time. The procedures of the American National Standards Institute require that action be taken periodically to reaffirm, revise, or withdraw this standard. Purchasers of American National Standards may receive current information on all standards by calling or writing the American National Standards Institute.

The developers of this standard have requested that holders of patents that may be required for the implementation of the standard, disclose such patents to the publisher. However, neither the developers nor the publisher have undertaken a patent search in order to identify which, if any, patents may apply to this standard.

As of the date of publication of this standard and following calls for the identification of patents that may be required for the implementation of the standard, no such claims have been made. No further patent search is conducted by the developer or the publisher in respect to any standard it processes. No representation is made or implied that licenses are not required to avoid infringement in the use of this standard.

**Printed in the United States of America**

Published by

**The Security Industry Association**

**8405 Colesville Road, Suite 500, Silver Spring MD 20910**

© SIA 2000-2019 — All rights reserved

# Contents

Page

Foreword.....	3
1. Scope.....	4
2. Normative references .....	4
2.1. Related Documents.....	4
2.2. Supporting Documents .....	5
2.3. Precedence .....	5
3. Conventions and Definitions .....	5
3.1. Conventions .....	5
3.1.1. Units of Measurement.....	5
3.1.2. Tolerances .....	6
3.1.3. Special Capitalization .....	6
3.1.4. Nomenclature and Identification of Clauses.....	6
3.1.5. Binding Language.....	6
3.2. Terms and definitions.....	6
4. Requirements .....	13
4.1. Partitioned Systems.....	13
4.2. User Caused False Alarm Mitigation.....	13
4.2.1. Annunciation .....	13
4.2.2. Arming and Exit.....	13
4.2.3. Entry and Disarming.....	15
4.2.4. Remote Control Devices.....	16
4.2.5. Alarm Transmission Sequence .....	16
4.2.6. Inadvertent Duress.....	18
4.2.7. Initiation of Manual Alarms .....	18
4.3. Sensor Caused False Alarm Mitigation .....	19
4.3.1. Cross Zoning .....	19
4.3.2. Swinger Shutdown.....	19
4.3.3. Fire Alarms .....	19
4.4. Power caused false alarm Mitigation .....	20
4.4.1. Power Variations .....	20
4.4.2. Labeling .....	20
4.4.3. Restoration of Power .....	20
4.5. Call Waiting (See Annex K) .....	20
4.6. Installation and Test .....	20

<b>4.6.1. Product Documentation .....</b>	<b>20</b>
<b>4.6.1.1. Quick Reference .....</b>	<b>20</b>
<b>4.6.2. Partitioned Systems.....</b>	<b>22</b>
<b>4.6.3. System Test .....</b>	<b>22</b>
<b>4.6.4. Initiation of Test .....</b>	<b>22</b>
<b>4.6.5. Communications .....</b>	<b>23</b>
<b>4.6.6. Test in Progress .....</b>	<b>23</b>
<b>4.6.7. Termination of Test.....</b>	<b>23</b>
<b>4.7. Default Settings .....</b>	<b>23</b>
<b>4.8. Mobile or Remote Device Response .....</b>	<b>23</b>
<b>Annex A.....</b>	<b>25</b>
<b>Annex B.....</b>	<b>27</b>
<b>Annex C.....</b>	<b>29</b>
<b>Annex D.....</b>	<b>32</b>
<b>Annex E.....</b>	<b>49</b>
<b>Annex F.....</b>	<b>50</b>
<b>Annex G.....</b>	<b>51</b>
<b>Annex H.....</b>	<b>53</b>
<b>Annex I.....</b>	<b>54</b>
<b>Annex J.....</b>	<b>55</b>
<b>Annex K.....</b>	<b>56</b>

## Foreword

This standard document is published by the Security Industry Association (SIA) and was developed and adopted by a consensus of industry volunteers in accordance with SIA's standards development policies and procedures. It is intended to facilitate product compatibility and interchangeability, to reduce misunderstandings between manufacturers and purchasers, and to assist purchasers in obtaining the proper products to fulfil their particular needs.

The existence of this or any SIA standards document shall not prevent any SIA member or non-member from manufacturing, selling, or using products not conforming to this or any SIA standard. SIA standards are voluntary. SIA encourages the use of this document but will not take any action to ensure compliance with this or any other SIA Standard. SIA assumes no responsibility for the use, application or misapplication of this document. Industry members using this document, particularly those having participated in its development and adoption, are considered by SIA to have waived any right they might otherwise have had to assert claims against SIA regarding the development process of this standard.

Although some SIA standards establish minimum performance requirements, they are intended neither to preclude additional product features or functions nor to act as a maximum performance limit. Any product the specifications of which meet the minimum requirements of a SIA standard shall be considered in compliance with that standard. Any product the specifications of which exceed the minimum requirements of a SIA standard shall also be considered in compliance with the standard, provided that such product specifications do not exceed any maximum requirements set by the standard. SIA standards are not intended to supersede any recommended procedures set by a manufacturer for its products.

SIA reserves the right to revise this document at any time. Because SIA policy requires that every standard be reviewed periodically and be revised, reaffirmed, or withdrawn, users of this document are cautioned to obtain and use the most recent edition of this standard. Current information regarding the revision level or status of this or any other SIA standard may be obtained by contacting SIA.

Requests to modify this document are welcome at any time from any party, regardless of membership affiliation with SIA. Such requests, which must be in writing and sent to the address set forth below, must clearly identify the document and text subject to the proposed modification and should include a draft of proposed changes with supporting comments. Such requests will be considered in accordance with SIA's standards development policies and procedures.

Written requests for interpretations of a SIA standard will be considered in accordance with SIA's standards development policies and procedures. While it is the practice of SIA staff to process an interpretation request quickly, immediate responses may not be possible since it is often necessary for the appropriate standards subcommittee to review the request and develop an appropriate interpretation.

Requests to modify a standard, requests for interpretations of a standard, or any other comments are welcome and may be sent to:

The Security Industry Association / 8405 Colesville Road, Suite 500 / Silver Spring, MD, 20910 / P (301) 804-4700 / F (301) 804-4701 / email: [standards@securityindustry.org](mailto:standards@securityindustry.org)

All rights reserved. Except as expressly granted by the Security Industry Association, no other implied or express license or right is made or granted by Security Industry Association to this work. Moreover, the documentation cannot be used, displayed, excerpted, modified, distributed, or offered for resale or use, without the prior written consent of the Security Industry Association.

# Security System Standard - Features for False Alarm Reduction

## 1. Scope

This standard details recommended design features for security systems and their associated devices to reduce the incidence of false alarms. These features are applicable to both residential and commercial properties protected by an electronic security system.

This standard is intended for use by manufacturers in the design of security systems and alarm signal receivers. It is also intended for reference by all affected parties, including security system installers, specifiers, and users; central station owners and operators; manufacturers of central station products, such as receivers and automation software; and local authorities.

This standard assumes that communications to the central station will be conducted by a robust contemporary communication protocol such as the SIA *Digital Communication Standard - "SIA Format" Protocol for Alarm System Communications*.

This standard is voluntary.

## 2. Normative references

### 2.1. Related Documents

Additional guidance on areas relating to this standard, as noted and otherwise, can be obtained from the sources below. All referenced standards are to the latest version, unless otherwise noted.

Features within this standard are, in part, based on data and recommendations from the following publications:

- Standards Committee Report (1994-1995), Central Station Alarm Association
- 1994 Study of False Alarms, Security Industry Association
- Model Cities Executive Summaries, Alarm Industry Research and Education Foundation (AIREF)

This standard is intended to allow compliance with the following standards:

#### National Fire Protection Association

- NFPA 72, National Fire Alarm Code
- NFPA 720, Standard for the Installation of Carbon Monoxide (CO) Detection and Warning Equipment

#### Underwriters Laboratories, Inc.

- ANSI/UL 268, Smoke Detectors for Fire Alarm Signaling Systems
- ANSI/UL 609, Local Burglar-Alarm Units and System
- ANSI/UL 827, Central Station Alarm Services

- ANSI/UL 681, Installation and Classification of Mercantile and Bank Burglar-Alarm Systems
- ANSI/UL 864, Control Units for Fire-Protective Signaling Systems
- ANSI/UL 985, Household Fire Warning System Units
- ANSI/UL 1023, Household Burglar-Alarm System Units
- ANSI/UL 1076, Proprietary Burglar Alarm Units and Systems
- ANSI/UL 2610, Commercial Premises Security Alarm Units and Systems
- ANSI/UL 1635, Digital Burglar Alarm Communicator System Units
- ANSI/UL 1641, Installation and Classification of Residential Burglar Alarm Systems
- ANSI/UL 2017, General Purpose Signaling Devices and Systems
- ANSI/UL 2034, Single and Multiple Station Carbon Monoxide Alarms
- UL 2050, National Industrial Security Systems
- ANSI/UL 2075, Gas and Vapor Detectors and Sensors
- UL 2610, Commercial Premises Security Alarm Units and Systems

The Monitoring Association

- ANSI/CSAA CSV-01, Alarm Confirmation, Verification and Notification Procedures

## **2.2. Supporting Documents**

The digital communications features detailed in this standard are supported by the Security Industry Association *Digital Communication Standard - "SIA Format" Protocol for Alarm System Communications*.

## **2.3. Precedence**

In the event of conflict between this standard and other reference documents mentioned herein, the order of precedence shall be:

- 1) National Fire Protection Association
- 2) Underwriters Laboratories, Inc.
- 3) this standard
- 4) other reference document

## **3. Conventions and Definitions**

### **3.1. Conventions**

#### **3.1.1. Units of Measurement**

In accordance with SIA Policy, the units of measurements used throughout this publication are the units of the System International d' Unites (SI), commonly known as metric units. Equivalent English Units, enclosed in parenthesis, are also used in this publication. These equivalent English Units are approximate conversions and are provided for easy reference.

### **3.1.2. Tolerances**

Unless otherwise specified, the tolerance for measurements specified within this standard shall be 10 percent ( $\pm 10\%$ ).

### **3.1.3. Special Capitalization**

Alarm sequence events, alarm system commands and states, and digital communication codes transmitted by the security system to the central station are capitalized within the text of this standard.

### **3.1.4. Nomenclature and Identification of Clauses**

Clauses and sub clauses within this standard are identified and referenced by the number preceding each clause. Unless otherwise specified, references to a clause refer to only that clause and not to subsequent sub clauses within the clause.

### **3.1.5. Binding Language**

This standard uses the term "shall" to convey binding requirements.

The term "may" is used to convey features that are allowed but not required.

Terms such as "is", "are", "will", and others are used to convey statements of fact for advisory purposes only.

The annotation "NOTE:" also precedes advisory information.

Where this standard is silent on a feature, the feature is permitted so long as it is not in conflict with the requirements contained herein.

A requirement is a feature that the security system must perform under all circumstances. A required option is a programmable feature that must be in the security system. An allowed option is a programmable feature that is not required or prohibited by the standard. An allowed feature is a non-programmable feature that is not required or prohibited by the standard.

Normative Annexes contain binding information.

## **3.2. Terms and definitions**

The terms and definitions listed below are for use within this standard in order to provide uniform use and understanding. For common industry nomenclature of terms used in describing security systems and events, please refer to Annex H.

### **3.2.1.**

#### **24-hour Alarm**

an alarm produced by a trip on a 24-hour zone.

### **3.2.2.**



**24-hour Zone**

a zone that is always active, usually used for smoke detectors or other types of life safety initiating devices

**3.2.3.****Abort**

a manual intervention after a system trip that prevents an alarm from being sent.

**3.2.4.****Abort Window**

a period of time after a sensor-initiated alarm condition that allows the user additional time to Disarm the system or withhold an alarm from transmitting.

**3.2.5.****Alarm**

a condition indicating a state of alert, duress, perimeter violation, or fire at the premises.

**3.2.6.****Alarm Signal**

a transmission of an alarm condition or alarm report.

**3.2.7.****Annunciator**

a low-level audio or visual display, whose purpose is to inform the system user of the condition or status of the security system or designated part of the security system.

**3.2.8.****Arm**

to turn on a security system, so that it will detect an unexpected entry.

**3.2.9.****Arming Station**

the part(s) of a security system from which a human operator can manually Arm and Disarm the system, manipulate the system operation, or otherwise interact with the system.

**3.2.10.****Away**

see *Full Arm*.

**3.2.11.****Bell**

a specific type of sounder which produces a ringing or gong sound through the striking of its hammer to its metal part or a simulation of the sound.

**3.2.12.****Cancel**

a transmission signal indicating that the previous alarm signal, or alarm in process, is to be disregarded.

**3.2.13.****Carbon Monoxide Zone**

a zone used to monitor carbon monoxide detectors (these zones typically are configured to respond differently than fire alarm zones) Generally, these zones should provide distinctive indication for carbon monoxide alarms and take precedence over supervisory or trouble signals.

**3.2.14.**

**Central Station (from ANSI/UL 827)**

A building, distributed group of buildings, or a distributed group of enclosed areas within a building that is occupied by the alarm service company that operates the central station, other businesses that are owned, and controlled by the alarm service company and which houses an operating room and equipment used to provide central-station service to protected properties.

**3.2.15.**

**Close**

the act of Arming a security system. (See Arm)

**3.2.16.**

**Communicator**

the part of the security system that sends electronic data outside the premises, typically to a central station.

**3.2.17.**

**Communicator Delay**

a period of time which elapses before the security system sends a transmission to the central station. See *Abort Window*.

**3.2.18.**

**Control**

See Control Panel.

**3.2.19.**

**Control Panel (Security System)**

the components of a system that handle control and communication, whether as combined or separate physical units, for monitoring a protected asset.

**3.2.20.**

**Credential**

any piece of authoritative information that is related to a specific individual and can be used to identify them. A credential is normally used to allow only authorized individuals the ability to gain admission through a portal in a facility.

**3.2.21.**

**Cross Zoning**

a configuring of logic within the security system such that two or more zones of the security system are interdependent in causing an alarm condition.

**3.2.22.**

**Delayed Zone**

a zone or circuit configured to provide a time delay, when tripped, before an alarm is generated.

**3.2.23.**

**Disarm**

to turn off a security system

**3.2.24.**

**Double Action Trigger**

a manual operation that requires two simultaneous or sequential actions.

**3.2.25.**

**Duress**

a signal that is activated by a user when they feel threatened due to one or more persons trying to force the user to enter or re-enter the premises

**3.2.26.**

**Entry Delay**

the period of time allowed, after entry to the premises, to Disarm the security system before the panel initiates an Alarm Transmission Sequence.

**3.2.27.**

**Entry/Exit Zone**

a delayed zone on the perimeter of the protected premises.

**3.2.28.**

**Exit Error**

a signal produced when an entry/exit zone is still violated at the expiration of the Exit Time.

**3.2.29.**

**Exit Time**

the period of time allowed, after Arming a security system, to exit the premises without tripping an alarm.

**3.2.30.**

**False Alarm**

an alarm transmission sent by the security system indicating the presence of an alarm condition when none exists.

**3.2.31.**

**Fire Alarm Verification**

an operation that helps ensure that an alarm condition persists by resetting a tripped sensor in a Smoke Detector zone and confirming that the sensor remained tripped or waiting for the sensor to re-trip within a set period of time. (e.g. if a low power RF smoke detector is self-resetting or auto-restoring, checking that the sensor trips more than once or remains tripped within a set period of time.) Fire alarm verification is meant to be a function of either the control panel or the sensor/detector. When "fire alarm verification" is a function of the control panel, delaying transmission of the fire alarm signal (after the initial sensor trip) until a second sensor trip occurs, within the confirmation period, meets the SIA CP-01 requirements.

**3.2.32.**

**Fire Zone**

a zone or circuit equipped with sensors designed to detect a fire condition (e.g. smoke, heat, etc.)

**3.2.33.**

**Full Arm**

an armed state of a security system where all zones and sensors are activated.

**3.2.34.**

**Holdup**

a signal indicating the presence of one or more criminals attempting to take goods or funds with implied or actual threat of force.

**3.2.35.**

**Home**

see *Stay Arm*.

**3.2.36.**

**Informative Signal**

signals requested by a subscriber to only be forwarded to a supervising station after the user has determined to do so. (Examples: Alarm to be verified, HVAC indicators, lighting status, viewing a local camera, location of something in its field of view, various household status indicators.)

**3.2.37.**

**Informative Zone**

a zone(s) that the subscriber has chosen for informative signal processing: the zone signal will be sent immediately to a selected mobile device, whereby the subscriber will “decide” what further action is to be taken. (See informative signal)

**3.2.38.**

**Instant Zone**

a non-24-hour zone that causes an alarm immediately upon being tripped.

**3.2.39.**

**Key Fob**

a type of *remote control device*.

**3.2.40.**

**Keypad**

see *arming station and mobile device*.

**3.2.41.**

**Local Alarm**

an alarm indication given at the protected premises by activation of a sounder.

**3.2.42.**

**Manual Reset**

the act of clearing an alarm condition in a security system by human intervention, either at an arming station or by remote control.

**3.2.43.**

**Mobile Device (Control Unit)**

A device (such as a smart cell phone) that can execute many or all, of the functions of a security system from most any location.

**3.2.44.**

**NRTL**

National Recognized Testing Laboratory (NRTL) is a United States Occupational Safety and Health Administration (OSHA) designation given to testing facilities that provide product safety testing, conduct follow up inspections of actual production, and certification services to manufacturers.

**3.2.45.**

**Open**

See Disarm.

**3.2.46.**

**Operating Code**

a numeric sequence used to control the alarm system, usually entered manually at a keypad or mobile device.

**3.2.47.**

**Option**

a functional or performance feature that is required by this standard but may be implemented as a selectable part of a product's performance capability.

**3.2.48.**

**Panic**

a general type of alarm initiated by a person in response to a threat

**Partition**

a defined area within the security system that can be Armed and Disarmed independent of the other area(s) but operated under a single security system. (Dedicated or shared user interfaces may be used to operate a partition.)

**3.2.49.**

**Point**

an electronically addressable sensor, sometimes used interchangeably with the term *sensor*. The term is usually used in multiplex alarm systems or for RF (wireless) sensors.

**3.2.50.**

**Premises**

the facility being protected by a security system.

**3.2.51.**

**Primary Power**

power provided by a commercial source that is normally available at the premises.

**3.2.52.**

**Recent Closing**

a transmission indicating that the security system has recently been Armed.

**3.2.53.**

**Report**

an electronic transmission sent by the security system to the central station containing detailed information about an event detected by or status of the security system.

**3.2.54.**

**Remote Access**

The act of accessing an security system at a distance from the protected premises, whereby the user does not have visual contact of the premises. Key-fobs are not included in this definition; because they are intended to be used when in visual contact with the protected premises and are very limited in the distance they may be used.

**3.2.55.**

**Remote Control Device**

Any device that can be used outside of the protected premises to control the functions of the security system, including proprietary; technologies, wifi, zigbee, z-wave. bluetooth, and others, also including off-premises, internet connected and mobile devices utilizing cellular technology.

These devices fall into two broad categories;

- 1) Those that perform their functions locally (within sight of the protected premises), like key-fobs, deadbolt sensors, and the like.
- 2) Devices that can perform remote access (see 3.2.53), locally and/or at great distances.

**3.2.56.**

**Secondary Power**

power provided from a secondary source, such as a battery or generator, upon the loss of primary power.

**3.2.57.**

**Silent Exit**

a user-initiated feature that silences the audible progress announcement of the exit delay.

**3.2.58.**

**Siren**

a type of *sounder*.

**3.2.59.**

**Sounder**

a high level audio device whose purpose is to alert person(s) at the protected premises of an alarm condition.

**3.2.60.**

**Stay Arm**

an armed state of a security system where some zones or sensors are active while other zones or sensors are made inactive, allowing occupants to be inside the protected premises without causing an alarm.

**3.2.61.**

**Swinger Shutdown**

an operating mode in which the security system, when a sensor or zone is repeatedly tripping, ignores the trips on that zone after a limited number of them.

**3.2.62.**

**Transmission**

an electronic message sent from the security system to the central station or remote station.

**3.2.63.**

**Trip**

an alarm state (of the security system) produced as a result of detection by a sensor.

**3.2.64.**

**User Code**

the numeric sequence of digits that correlates to a valid user number.

**3.2.65.**

**User Interface**

see *arming station*.

**3.2.66.**

**User Number**

an identification number assigned to a person who operates or has access to the security system, or a default identification number assigned to a security system for quick Arming of the system.

**3.2.67.**

**Violated**

a condition at the premises detected by a sensor that causes a trip of the security system.

**3.2.68.**

**Withheld and Withhold**

an action, initiated by a user that has decided an informative signal will not be transmitted to the supervising station. (See Informative Signals & Informative Zone)

### **3.2.69.**

#### **Zone**

a dedicated input to the security system containing one or more sensor devices which will trip that input upon activation of any one sensor device.

### **3.2.70.**

#### **Zone Type**

an identifier for a set of attributes that define how a zone will respond to various changes in its inputs. An example of an attribute is the response to a short circuit when the system is in a disarmed state. Examples of zone types are Fire, Interior Burglary, Perimeter Burglary, etc.

## **4. Requirements**

All security systems shall be NRTL listed to be compliant with the appropriate UL standard as found in section 2.1 Related Documents, Underwriters Laboratories, Inc. and shall be labeled accordingly.

Panels that are listed as compliant with the current version of this standard are considered compliant with earlier versions of this standard.

### **4.1. Partitioned Systems**

Partitioned systems shall provide the requirements of Clause 4.2 User Caused False Alarms, 4.3 Sensor Caused False Alarms, and 4.6 Installation and Test for each partition. Each partition shall be able to support the requirements in Clause 4. In testing, it will be acceptable to test 2 partitions as indicative of the product's ability to meet the requirements in all partitions.

When silent exit is used in a partitioned system it shall meet the same requirements as for non-partitioned systems.

#### **4.1.1 Independent Partitions – Option**

If the system is operated as a partitioned system, with each partition being operated independently, each partition shall behave as if there were no other partitions, incorporating all of the features of this standard, except where excluded in this standard. Abort reports and exit error reports transmitted to the central station must include the correct partition information in the report.

### **4.2. User Caused False Alarm Mitigation**

#### **4.2.1. Annunciation**

The security system shall support an output capability (may be wireless) to activate an auxiliary annunciation device for all sounds required by this standard.

The security system shall support annunciation of exit and entry time in multiple locations within the premises.

#### **4.2.2. Arming and Exit**

To reduce the incidence of false alarms during Full Arming or automatic Arming, the following shall be required except as noted in clause 4.2.4.4 Remote Arming. An Auto-arming option may exist and when enabled must meet all of the requirements of clause 4.

##### **4.2.2.1 Exit Time**

A programmable Exit Time shall be included. The programmable range for all Exit Times shall be from forty- five (45) seconds to at least two (2) minutes, but shall not exceed two hundred and fifty-five (255) seconds. The security system default setting for all Exit Times shall be sixty (60) seconds. The minimum time shall be 45 seconds.

If the security system supports a silent exit feature and it has been invoked, the Exit Time shall be doubled for that exit period only but shall not exceed two hundred and fifty-five (255) seconds.

#### **4.2.2.2 Progress Annunciation**

The security system shall annunciate a distinct pulsating audible sound throughout the duration of the Exit Time to warn person(s) still within the premises that the exit period is in process.

An audible annunciation, whose pulsating rate is distinctly different, shall sound during the last ten (10) seconds of the Exit Time to warn person(s) that the Exit Time is running out.

A security system may meet this requirement by having two separate buttons for arming where one is arm normal (with progress annunciation) and one is arm silent (no annunciation).

If the security system supports a silent exit feature and it has been invoked, the audible progress annunciation shall be silenced on one or more keypads for that exit period only. The security system shall not allow progress annunciation to be disabled for the entire system, but may allow annunciation to be disabled for individual keypads.

#### **4.2.2.3 Exit Time Restart**

An option shall be provided where violation, restoral, and then a second violation of an entry/exit zone prior to the end of the Exit Time shall restart the Exit Time. The panel shall not allow the Exit Time to be restarted more than once. The default setting for this option shall be that it is enabled.

Panels may have this feature disabled at the time of installation.

If the security system supports a silent exit feature and it has been invoked, the audible progress annunciation shall remain silenced during the additional Exit Time, and the duration of the additional Exit Time shall be doubled for that additional exit period only but shall not exceed two hundred and fifty-five (255) seconds.

#### **4.2.2.4 Exit Error**

An Exit Error sequence shall be initiated if an entry/exit zone is in a violated state or condition at the instant of exit time expiration. This section applies to entry/exit zones only. All non-entry/exit type zones will adhere to the manufacturer's specifications relative to Exit Error

An Exit Error shall be processed as follows:

- The local alarm shall immediately sound.
- The annunciator shall sound an Entry Delay or an alarm condition.
- An Entry Delay shall be initiated.
- If the alarm system is not Disarmed at the end of the Entry Delay, the Alarm Transmission Sequence shall be initiated.
- The Alarm Transmission shall include the alarm and an Exit Error message to the central station.

#### **4.2.2.5 Unvacated Premises**



An option shall be provided which allows the security system to Arm in the Stay Arm mode if the Exit Time expires and no exit has been made. The default setting for this option shall be that it is enabled.

This option, if enabled, is required to be invoked when the system is Armed Away by the user from within the protected area and when areas of the system have “Stay” and “Away” arming states.

This option is not required when arming occurs by time schedule or is performed with a remote-control device.

#### **4.2.2.6 Recent Closing**

A Recent Closing transmission shall be sent if an alarm occurs within two (2) minutes after the expiration of the Exit Time. If the user number is available, it shall be included in the Recent Closing transmission.

Recent Closing transmissions are not required for Fire alarms. A Recent Closing transmission is allowed, but not required, if an alarm condition occurs between Arming and the end of the Exit Time. The Recent Closing signal is separate from the closing signal.

### **4.2.3. Entry and Disarming**

To reduce the incidence of false alarms during Entry and Disarming, the following shall be required for all armed states.

#### **4.2.3.1 Entry Delay**

Programmable Entry Delays shall be included. The programmable range for all Entry Delays shall be from thirty (30) seconds to at least four (4) minutes. The security system default setting for all Entry Delays shall be thirty (30) seconds. If the system is not disarmed during the Entry Delay, the Alarm Transmission Sequence shall begin when the Entry Delay expires.

The minimum time given is an absolute minimum, and panels are not to allow Entry Delay(s) of less than 30 seconds.

Exception: For commercial, high security installations, under UL 2050, “National Industrial Security” requirements and compliant with the appropriate UL end product standards or specifications by the Authority Having Jurisdiction or Facility Security Office, this value may be adjusted at the time of installation, outside the range of this standard.

Note: The quick reference guide and user manual documentation supplied with the panel must describe the entry delay characteristics of the panel; see section 4.6.1.

#### **4.2.3.2 Progress Annunciation**

A distinct annunciation shall be produced upon entry to warn person(s) entering the premises that the Entry Delay has begun. This annunciation shall be distinct from the annunciation produced when the system is in alarm. The progress annunciation of an entry delay needs to be audible at a minimum.

#### **4.2.3.3 Disarm**

When the system is in an Entry Delay the system shall Disarm by a single step procedure. Procedures may include the entry of a user code (without additional keys) or the presentation of a credential. Systems may implement one or both of these procedures. Alternative disarming methods may co-exist.

Progress annunciation shall be silenced upon entry of the first digit of the user code. Progress annunciation shall resume upon entry of an invalid user code or after a manufacturer specified time during the Entry Delay.

If multiple keypads are annunciating the entry delay, one or more keypads may be momentarily silenced.

#### **4.2.4. Remote Control Devices**

Devices that remotely control the functions of the alarm system, if used, shall have the following features.

##### **4.2.4.1 Control Buttons**

Remote control device buttons, including Duress, Holdup and Panic, shall be designed in such a way so that inadvertent activation of remote commands shall be minimized.

The requirements applied for system control buttons are not the same those as for buttons to initiate manual alarms (see section 4.2.4.2) . Control buttons (arm, disarm, etc.) only need to implement the design features to prevent inadvertent activation, not the dual action requirements of section 4.2.4.2. For testing, the manufacturer may need to provide (in their product literature or otherwise) rationale on their design and how it helps minimize inadvertent activation.

##### **4.2.4.2 Manual Alarms**

The requirements of clause 4.2.7 Initiation of Manual Alarms shall be met when activating manual alarms by remote control devices. Testing to comply with Manufacturers specification.

##### **4.2.4.3 System Acknowledgment**

The security system shall provide acknowledgment of Arm and Disarm commands from the remote control device such that the acknowledgment can be discerned from the exterior of the premises. Acknowledgment of Arm and Disarm may or may not be unique.

##### **4.2.4.4 Remote Arming**

When the system is Armed using a remote-control device, the security system may be programmed to Arm the system without an Exit Time and the associated progress annunciation as described in clause 4.2.2.1 Exit Time through 4.2.2.6 Recent Closing. The default configuration for the security system shall be to Arm the system using the Exit Time and progress annunciation.

##### **4.2.4.5 Remote Disarming**

When the system is Disarmed using a remote-control device, such that an Entry Exit Zone is not violated prior to disarming the system, the progress annunciation described in clause 4.2.3.1 through 4.2.3.3 will not start.

#### **4.2.5. Alarm Transmission Sequence**

To reduce the incidence of false alarms during alarm transmissions, the following sequence of events shall be required.

##### **4.2.5.1 Abort Window**

A programmable Abort Window shall be included for all non-fire zones. During an Abort Window, the local alarm shall sound and the annunciator shall annunciate an alarm. NFPA requirements shall still be met when the Abort Window is applied to any fire zone.

Exception: For commercial, high security installations, for application under National Industrial Security requirements and compliant with the appropriate UL standards or specifications by the authority having jurisdiction or facility security officer, this value may be adjusted at time of installation, outside the range of this standard.

Exception: Fire, carbon monoxide, gas detection and similar life safety zones do not require an abort window.

Exception: Duress and silent alarm zones are not required to sound.

The abort window may be disabled for each zone or zone type individually. The default setting for the Abort Window shall be that it is enabled for all zones and zone types that require programmable abort window. It shall not be possible to globally disable the abort window using a single system-wide option.

The programming for the Abort Window shall be as follows:

**Table 1 — Programming for the Abort Window**

Programming Range:	
Minimum	no minimum
Maximum	45 sec
Default Time	30 sec
May be Disabled	By Zone or Zone Type

NOTE: In accordance with UL standards, this standard intends that the aggregate of the Entry Delay and Abort Window will not be programmed to exceed one minute.

Provided that a panel provides an abort window to be enabled by zone or by zone type, setting a single abort window to "0" is acceptable.

#### **4.2.5.1.1 Disarm**

When the system is in an alarm condition, the system shall Disarm by a single step procedure. Procedures may include the entry of a user code (without additional keys) or the presentation of a credential. Systems may implement one or both of these procedures. Alternative disarming methods may co-exist.

When systems require entry of a user code, alarm annunciation at the keypad shall be silenced upon entry of the first digit of the user code. Alarm annunciation shall resume upon entry of an invalid user code or after a manufacturer specified time during the Abort Window.

#### **4.2.5.1.2 Abort**

If the alarm system is Disarmed within the Abort Window, no alarm transmission shall occur.

An option shall be provided that the alarm system will annunciate that no alarm signal was transmitted. The default setting for this option shall be that it is enabled.

NOTE: A transmission may be sent indicating that an alarm has been aborted.

#### **4.2.5.2 Alarm Transmission**

The Alarm Transmission shall occur at the end of the Abort Window.

### **4.2.5.3 Disarm**

Upon disarming the system after any alarm has been reported (except for a Duress alarm), the panel shall indicate that an alarm had occurred and shall, at a minimum, indicate which zone(s) had been violated during the armed period.

### **4.2.5.4 Cancel Window**

A period of time shall be provided, starting at the end of the Abort Window, during which a user can Cancel the alarm. The minimum duration of the window shall be five (5) minutes. The Cancel Window shall apply to all alarms that have been subjected to the Abort Window.

#### **4.2.5.4.1 Cancel**

If an alarm has previously been transmitted, a Cancel signal shall be transmitted if either the alarm system is Disarmed, or both a Disarm and function key are depressed during the Cancel Window. Some panels may require a special function key after Disarm to send a Cancel signal.

An option shall be provided that the alarm system will annunciate that a Cancel was transmitted. The default setting for this option shall be that it is enabled.

An option may be provided to delay the Cancel signal and other non-alarm signals until after termination of either an active two-way voice or video verification session, in the instance that the end user initiates a cancel sequence while a two-way voice or video verification session is already in progress.

Exception: For commercial, high security installations, for application under National Industrial Security requirements and compliant with the appropriate UL standards or specifications by the authority having jurisdiction or facility security officer, this value may be adjusted at time of installation, outside the range of this standard.

## **4.2.6. Inadvertent Duress**

To reduce the incidence of inadvertent Duress signals, the following shall be required.

### **4.2.6.1 Use of Duress Feature**

If a Duress feature is provided, its default setting shall be that it is disabled.

### **4.2.6.2 Duress Code**

A Duress signal shall be sent by a unique Duress code only. The security system shall not derive the Duress code from an existing operating code such as a "user code plus Duress digit" sequence. The security systems shall not allow duplication of any operation code including Duress codes.

## **4.2.7. Initiation of Manual Alarms**

Alarms that are manually initiated at an arming station or through remote access shall require a double action trigger. A single button which must be held to initiate the manual alarm does not comply with this requirement.

NOTE: Implementation of this feature may include, but is not limited to, any of the following:

- Simultaneous depression of two buttons, where if either of the buttons have multiple functions, the two buttons are non-adjacent (i.e., can't be pressed with one fingertip). Two adjacent digit keys may not be

assigned for this feature unless there is a specific provision with distance or other design features that prevents accidental depression with one fingertip.

- Depression of a single button after lifting the cover that normally protects it, if the cover protects only emergency function buttons.
- Tapping an emergency icon, then tapping a specific emergency icon on the next menu.

### **4.3. Sensor Caused False Alarm Mitigation**

To reduce the incidence of false alarms caused by sensors, the following shall be required.

#### **4.3.1. Cross Zoning**

When a cross zoning option, is included it shall have the following features:

- The cross zone option shall be programmable by zone.
- The cross zone option shall require a trip on two zones, within a given time period, to start an Alarm Transmission Sequence as described in Clause 4.2.5 Alarm Transmission Sequence and its sub-clauses.
- The time period shall be initiated by the trip of the first zone.
- The time period shall be programmable or specified by the manufacturer, and shall be consistent with the requirements of any UL standards for which the panel is listed.

The default setting for the cross zone option shall be that it is disabled.

NOTE: When the time period elapses without the trip of the second zone, it is recommended that an error transmission be sent that reports a trip in a cross zone was not verified.

#### **4.3.2. Swinger Shutdown**

A programmable swinger shutdown shall be required for each burglary type zone, such that a programmable one to as many as six trip(s) shall shut down the zone. The zone shall be restored by a manual reset or may be reset automatically after eight (8) or more hours with no further trips on the zone. The default setting for this option shall be two trips for swinger shutdown.

NOTE: Zones disabled by swinger shutdown shall not transmit restoral signals until they are returned to service by either of the following events:

- After the panel is disarmed or:
- After disarming and then rearming.

NOTE: A Swinger Trouble code may be transmitted upon the occurrence of additional trips on the zone.

NOTE: Swinger shutdown may be disabled on any non-fire zone that does not require police response.

#### **4.3.3. Fire Alarms**

Fire alarm verification shall be an available option on fire zones. When used, the system shall begin an Alarm Transmission Sequence once the conditions for fire alarm verification are met. The default setting for the fire alarm verification option shall be that it is disabled.

#### **4.3.4 Carbon Monoxide Alarms**

The requirements of this standard for alarm delay and alarm verification shall not apply to zones used for carbon monoxide detectors.

### **4.4. Power caused false alarm Mitigation**

To reduce the incidence of false alarms caused by power problems, the following shall be required.

#### **4.4.1. Power Variations**

The security system shall prevent false alarms due to variations of primary and secondary power sources, or due to complete loss of primary or secondary power or both.

#### **4.4.2. Labeling**

In order to allow the installer to match the operating ranges of sensors to the operating range of the security system, the panel shall specify, on the interconnect label, information that allows an installer to confirm compatibility between the panel zone inputs and the sensors selected for the installation. An example is provided in Annex J.

#### **4.4.3. Restoration of Power**

Upon the restoration of power after a complete loss of primary and secondary power, the security system shall resume operation in the same Arm state and with the same zones bypassed as when the panel lost primary and secondary power. The panel shall disregard input from all sensors for a minimum of sixty (60) seconds from the time of the primary power restoration. The panel arming state shall be retained no less than fourteen (14) days during a power loss.

### **4.5. Call Waiting (See Annex K)**

### **4.6. Installation and Test**

To assist in both the installation and testing of panels to this standard, the following shall be required.

#### **4.6.1. Product Documentation**

##### **4.6.1.1. Quick Reference**

A quick reference chart or card for the installer detailing the programming locations and testing procedures associated with the features of this standard shall be included. Features that the security system does not implement are not required to be included in the quick reference. The quick reference section may be contained in the installation manual so long as it is a separate section. Refer to table 2 for features to be included in the quick reference.

##### **4.6.1.2 User Manual Requirements**

The operation of CP-01 features that interact directly with the user shall be documented in the user manual. Features that the security system does not implement are not required to be included in the user manual. Refer to table 2 for features to be included in the user manual.

Text similar to the following is required to describe the operation of the abort feature (4.2.5.1.2):

“Consult with your installer to determine if your system is configured with a communicator delay. A communications delay will prevent a report to the central station if the security system is disarmed within 30-45 seconds after an intrusion alarm is triggered. Note that fire-type alarms are normally reported without a delay.”

**Table 2 – Quick Reference and User Manual Requirements**

<b>Section</b>	<b>Feature</b>	<b>Quick Reference Requirements</b>	<b>User Manual Requirements</b>
4.2.2.1	Exit Time	must document	must document
4.2.2.2	Progress Annunciation	must document if programmable	must document
4.2.2.3	Exit Time Restart	must document	must document
4.2.2.4	Exit Error	must document if programmable	not required in user manual
4.2.2.5	Unvacated Premises	must document	must document
4.2.2.6	Recent Closing	must document if programmable	not required in user manual
4.2.3.1	Entry Delay	must document	must document
4.2.3.2	Progress Annunciation	must document if programmable	must document
4.2.3.3	Disarm	not required in quick reference	must document
4.2.4.1	Control Buttons	not required in quick reference	must document
4.2.4.2	Manual Alarms	not required in quick reference	must document
4.2.4.3	System Acknowledgment	must document if programmable	must document
4.2.4.4	Remote Arming	must document if programmable	must document
4.2.4.5	Remote Disarming	not required in quick reference	not required in user manual
4.2.5.1	Abort Window	must document	see 4.2.5.1.1, 4.2.5.1.2
4.2.5.1.1	Disarm (Abort)	must document if programmable	must document
4.2.5.1.2	Abort	must document if programmable	must document
4.2.5.2	Alarm Transmission	not required in quick reference	not required in user manual
4.2.5.3	Disarm	not required in quick reference	must document
4.2.5.4	Cancel Window	must document if programmable	must document
4.2.6.1	Use of Duress Feature	must document	see 4.2.6.2

4.2.6.2	Duress Code	must document	must document
4.2.7	Initiation of Manual Alarms	not required in quick reference	must document
4.3.1	Cross Zoning	must document	must document
4.3.2	Swinger Shutdown	must document	must document
4.3.3	Fire Alarms	must document	must document
4.5	Call Waiting	must document	must document
4.6.3	System Test	must document	must document
4.6.4	Initiation of Test	not required in quick reference	not required in user manual
4.6.5	Communications	must document	not required in user manual
4.6.6	Test in Progress	not required in quick reference	must document
4.6.7	Automatic Termination of Test	not required in quick reference	must document
4.8.4	Informative Signals	must document, if present	must document, if present

#### **4.6.1.3 Remote Access Documentation**

When remote access is implemented, there shall be documentation on the use of the remote access features. The listing features indicated above (Table 2) shall be used as a guide for the functions that are to be documented.

#### **4.6.1.4 Alarm System Configuration Identification**

For system configurations comprised of interchangeable components (e.g. control equipment, arming station, annunciator, local alarm, communicator, sub assembly, etc.) a list of components that comprise of the CP-01 compliant system shall be provided. The list shall be prominently available as part of the equipment's installation manual and shall include applicable information such as model numbers of the system components, so that the complaint minimum system configuration is identified.

If required, there shall be a detailed listing of other items, both physical and/or logical, that are required for proper system functioning.

NOTE: For remote access configurations the remote connection application software shall be identified as an element of the system configuration.

#### **4.6.2. Partitioned Systems**

For partitioned systems, the requirements of clause 4.6 Installation and Test and its subclauses shall be capable of being implemented independently for each partition.

#### **4.6.3. System Test**

A mode of operation that allows testing of all zones, the control, all sounders, and the communicator shall be included. A procedure outlined in the manuals is an acceptable alternative to a special mode of operation.

#### **4.6.4. Initiation of Test**



#### **4.6.4.1 Security Systems Status**

The security system shall ensure that a system test cannot be initiated from an armed state.

#### **4.6.4.2 Initiation Report**

At the initiation of a test, the security system shall send a message to the central station that a test is in progress. The message shall include the user number if it is available.

### **4.6.5. Communications**

Communication with the monitoring station regarding the partition(s), zones, or points and sensors under test shall be inhibited for the duration of the test except for the requirements of clause 4.6.4.2 Initiation Report.

A feature may be provided to transmit test signals. The default setting for this feature, if provided, shall be disabled.

### **4.6.6. Test in Progress**

During a test, the security system shall give a clear, prominent, and continuous indication that the system is being tested. This indication shall be made at all wired system arming stations.

### **4.6.7. Termination of Test**

#### **4.6.7.1 Automatic Termination**

When a panel automatically terminates a test, the panel shall annunciate an audible warning, different from the annunciation specified in clause 4.6.6 Test in Progress, beginning five (5) minutes prior to the termination of the test.

#### **4.6.7.2 State at Termination**

Termination of a test shall leave the security system in a disarmed state. 24 hour alarm zones are exempt from this requirement. Should a point in a 24 hour alarm zone be in violation at the termination of a test, the panel shall suppress the alarm and treat the zone as a trouble condition. The standard does not prohibit the annunciation and/or the reporting of fire alarm trouble during a test mode.

#### **4.6.7.3 Termination Report**

When a test is terminated, the security system shall send a message to the central station that the test is over.

## **4.7. Default Settings**

All features of this standard implemented as selectable options shall be selected as the factory default except where otherwise indicated. Default settings are listed in Annex A.

## **4.8. Mobile or Remote Device Response**

### **4.8.1. Alarm System Controlled/Access Capability**

- 4.8.1.1.** All actions performed by the remote or mobile device shall be authorized by the alarm system based on the level of authorization of the user.

- 4.8.1.2. Actions of remote or mobile devices shall be consider equivalent to all other authorized actions.
- 4.8.1.3. Activity that is transmitted to the supervising station, as a result of a mobile or remote device, shall be distinctive from activity performed directly on the security system.

#### 4.8.2. **Direct Signaling Functions and Considerations**

When a device is not directly connected to an alarm system and is capable of initiating alarm signals, special considerations below shall be implemented.

##### 4.8.2.1. **Signals that Expect Immediate AHJ Response**

(Examples: Holdup Alarm, Ambush, and the like)

- 4.8.2.1.1. These types of signals shall conform to the appropriate sections covering the same types of signals and responses as a wired alarm system.

Exception: Signaling designed to indicate a “personal emergency” shall perform as contracted.

#### 4.8.3. **Direct Control of the Alarm System**

When a device, is not directly connected to an alarm system, and is capable of affecting the status of the alarm system, special considerations shall be implemented.

#### 4.8.4. **Monitoring Informative Signals**

- 4.8.4.1. Informative signals, generated by Informative Zones shall be transmitted to the user’s mobile/remote device.

- 4.8.4.2. Should the user determine that the received signal requires action or attention of the supervising station, the user shall retransmit the signal to the supervising station, along with a message indicating that action is requested.

- 4.8.4.3. If the subscriber decides no action is needed by the supervising station, the alarm system will log and send a distinctive signal, including the zone-id, to the supervising station indicating a signal has been “withheld.”

- 4.8.4.4. If no action is taken by the user and the abort timer expires, the signal shall be sent to the supervising station as expected.

- 4.8.4.5. User information (if available) shall be transmitted at the time as the distinctive signal.

## Annex A (informative) Programmable Features

**Table A.1 — Shipping Defaults and Recommended Programming**

PARAGRAPH	FEATURE	REQUIREMENT	RANGE	SHIPPING DEFAULT	RECOMMENDED PROGRAMMING *
4.2.2.1	Exit Time	Required (programmable)	For full or auto arming: 45 sec. - 2 min. (255 sec. max.)	60 Seconds	60 Seconds
4.2.2.2	Progress Annunciation / Disable - for Silent Exit	Allowed	Individual keypads may be disabled	All annunciators enabled	All annunciators enabled
4.2.2.3	Exit Time Restart	Required Option	For re-entry during exit time	Enabled	Enabled
4.2.2.5	Auto Stay Arm on Unvacated Premises	Required Option (except for remote arm)	If no exit after full arm	Enabled	Enabled
4.2.4.4	Exit Time and Progress Annunciation / Disable - for Remote Arm	Allowed Option (for remote arm)	May be disabled - for remote arming	Enabled	Enabled
4.2.3.1	Entry Delay(s)	Required (programmable)	30 sec. - 4 min. **	30 Seconds	At least 30 Seconds ** (See exception in paragraph 4.2.3.1)
4.2.5.1	Abort Window – for Non-Fire Zones	Required Option	May be disabled - by zone or zone type	Enabled	Enabled (all zones) (See exception in section 4.2.5.1)
4.2.5.1	Abort Window Time – for Non-Fire Zones	Required (programmable)	up to 60 sec.**	30 Seconds	At least 15 seconds **
4.2.5.1.2	Abort annunciation	Required Option	Annunciate that no alarm was transmitted	Enabled	Enabled
4.2.5.4	Cancel Window	Required	Minimum duration of the window shall be five (5) minutes.		Not required to be programmable. (See exception in section 4.2.5.1)
4.2.5.4.1	Cancel Annunciation	Required Option	Annunciate that a Cancel was transmitted	Enabled	Enabled

PARAGRAPH	FEATURE	REQUIREMENT	RANGE	SHIPPING DEFAULT	RECOMMENDED PROGRAMMING *
4.2.6.1 & 4.2.6.2	Duress Feature	Allowed Option	No automatic derivative of another user code  No duplicates with other user codes	Disabled	Disabled
4.3.1	Cross Zoning	Required Option	Programming needed	Disabled	Enabled and two (or more) zones programmed
4.3.1	Programmable Cross Zoning Time	Allowed	May Program	Per manufacturer	Per walk path in protected premises
4.3.2	Swinger Shutdown	Required (programmable)	For all non-fire zones, shut down at 1 to 6 trips	Two trips	Two trips
4.3.2	Swinger Shutdown Disable	Allowed	For non- police response zones	Enabled	Enabled (all zones)
4.3.3	Fire Alarm Verification	Required Option	Depends on panel and sensors	Disabled	Enabled unless sensors can self verify
4.5	Call Waiting Cancel	Required Option	Depends on user phone line	Disabled	Enabled if user has call waiting
4.8.4	Informative Zone	Allowed	Zones may or may not be selected by the Subscriber.	Disabled	Disabled

\* Programming at installation may be subordinate to other UL requirements for the intended application.

\*\* Combined Entry Delay and Abort Window should not exceed 1 minute.

## Annex B (informative) Arming, Disarming, and Transmission Sequences

**Table B.1 — System Arming and Exit Sequence — Clause 4.2.2**

Event	Time	Action	Comments
Exit Time Clause 4.2.2.1	45 to between 120 to 255 seconds. Default = 60 seconds	Initiates Progress Annunciation.	Time doubles if the silent exit feature is invoked.
Progress Annunciation Clause 4.2.2.2	During Exit Time.  Last 10 seconds of Exit Time.	Audible Annunciation.  Distinct Audible Annunciation.	Disabled if the silent exit feature is invoked.  Default: Annunciate ON
2nd Violation of Entry/Exit Zone	During Exit Time. Clause 4.2.2.3	May Restart Exit Time One Time Only	2nd Violation = violation, restore, violation of entry/exit zone
Violated Entry/Exit Zone	End of Exit Time Clause 4.2.2.4	Initiates an Exit Error Sequence.	
Arm	End of Exit Time.	Arms the Alarm System.	Option: Shall Stay Arm if no exit was made during Exit Time. Clause 4.2.2.5
Alarm	Within 2 minutes of the end of the Exit Time. Clause 4.2.2.6	Transmit Recent Closing.	Include user number in transmission if available. Not required for Fire alarms.

**Table B.2 — Entry and System Disarming Sequence — Clause 4.2.3**

Event	Time	Action	Comments
Entry Delay Clause 4.2.3.1	30 seconds to ≥4 minutes. Default = 30 seconds	Initiates Progress Annunciation.	(See exception in paragraph 4.2.3.1)
Progress Annunciation Clause 4.2.3.2	During Entry Delay.	Audible Annunciation.	
Disarm Clause 4.2.3.3	Prior to Expiration of the Entry Delay.	Disarms the Alarm System.	System shall Disarm by, at a minimum, entry of the user code only.
Withhold Clause 4.8.4	Prior to expiration of the Entry & Abort Delay's.	Leaves status as found	Withhold signal sent to CS, system logs remote user and status as found

**Table B.3 — Alarm Transmission Sequence — Clause 4.2.5**

Event	Time	Action	Comments
Abort Window Clause 4.2.5.1	Non-Fire: 15 to 60 seconds.	Sounds the Local Alarm. Annunciator Sounds Alarm Condition.	May disable by zone / zone type  Default time: Non-Fire = 30 sec.  (See exception in section 4.2.5.1)
Disarm Clause 4.2.5.1.1 & 4.2.5.1.2	During Abort Window.	Aborts the Alarm Transmission Sequence.	System shall Disarm by entry of the user code only. Option - Annunciate that no Alarm Transmission was made.
Transmit Alarm Clause 4.2.5.2	End of the Abort Window.	Transmits Alarm Signal.	
Cancel Window Clause 4.2.5.4	Starts at the end of the Abort Window. ≥ 5 minutes		Applies to all alarms that have been subject to the Abort Window.  (See exception in section 4.2.5.4.1)
Disarm or Disarm + Function Key Clause 4.2.5.4.1	During the Cancel Window.	Transmit a Cancel Signal.	Cancel Signal is transmitted during the Cancel Window if an alarm was previously transmitted.
Disarm Clause 4.2.5.3	After an alarm report.	Disarms the Alarm System.	Panel will indicate an alarm occurred and which violated zone(s) caused the alarm.



**Exit Error - System Arm with entry/exit zone in violation at the end of the Exit Time** (Clause 4.2.2.1, 4.2.2.2, 4.2.2.4 and 4.2.5)

TIME (MIN/SEC)                      :00                      :50                      1:00                      1:30                      2:00

<b>SYSTEM STATE</b>	Unarmed	Exit Time		Entry Delay	Abort Window	Alarm Transmission	
<b>ANNUNCIATOR</b>		Exit Annunciation	Unique	Entry or Alarm Annunciation	Alarm Annunciation		
<b>LOCAL ALARM</b>				Sounds	Sounds until alarm time-out		
<b>COMMUNICATION</b>							

User Arms the Alarm System ®                      — Entry/exit zone violated between times :00 and 1:00 and remains violated at the end of the Exit Time

**System Entry and Disarm** (Clause 4.2.3)

TIME (MIN/SEC)                      :00                      < :30

<b>SYSTEM STATE</b>	Armed	Entry Delay	Disarmed	
<b>ANNUNCIATOR</b>		Entry Annunciation		
<b>LOCAL ALARM</b>				
<b>COMMUNICATION</b>				

Violation of an entry/exit (delayed) zone ®                      — Entry of Valid Disarm code

**Trip of entry/exit zones** (Clause 4.2.3 and 4.2.5)

TIME (MIN/SEC)                      :00                      :30                      1:00

<b>SYSTEM STATE</b>	Armed	Entry Delay	Abort Window	Alarm Transmission	
<b>ANNUNCIATOR</b>		Entry Annunciation	Alarm Annunciation		
<b>LOCAL ALARM</b>					Sounds until alarm time-out
<b>COMMUNICATION</b>					

Violation of a delayed zone ®

**Trip of non-entry/exit and non-Fire zones** (Clause 4.2.5)

TIME (MIN/SEC)                      :00                      :30

<b>SYSTEM STATE</b>	Armed	Abort Window	Alarm Transmission	
<b>ANNUNCIATOR</b>		Alarm Annunciation		
<b>LOCAL ALARM</b>				
<b>COMMUNICATION</b>				

Violation of an instant zone ®





## Annex D (informative) Recommended Self Validation Procedures

The following procedures are intended to ascertain compliance with the requirements of the Security Industry Association's *Security System Standard - Features for False Alarm Reduction*. These procedures are intended for use by the manufacturer to validate their design and for use by UL or other nationally recognized testing laboratories (NRTL) to confirm compliance.

Although a security system can be validated as a stand alone unit, these procedures are written for a system test where various peripherals (sensors, annunciators, etc.) are used with a security system. They refer to the security system being tested (including its arming stations) as the Unit Under Test (UUT).

These procedures are organized by the clauses of their associated requirements in the standard to provide convenient reference, but they are not intended to suggest the sequence of testing. While all features should be tested, it is understood that individual product implementations will dictate optimum sequencing of tests.

These procedures assume that, unless otherwise specified:

- all programmable options are initially programmed to the default settings specified in the standard
- the UUT is Disarmed and returned to its default configuration after each test, noted as End of Test (EOT)

These procedures are generic and highlight various implementation details specific to an individual UUT in *italics print*, where the standard allows certain freedom of design.

These procedures are non-binding and are not intended to add to or supplant the requirements of the standard. When the requirements of the standard and these procedures appear to be in conflict, the requirements of the standard have precedence.

VALIDATION PROCEDURE	REFERENCE
<b>Pre-test</b> Verify that all selectable options of the UUT are defaulted as listed by the table in Appendix A of the standard. (Refer to the UUT's quick reference chart or card.)	4.7 & Appendix A (4.6.1)

**SECTION 1 USER CAUSED FALSE ALARMS** (to be performed on each partition of the UUT)

VALIDATION PROCEDURE	REFERENCE
<p><b>VP 1 Panel Annunciation</b></p> <ul style="list-style-type: none"> <li>• Verify that the UUT has an output for an auxiliary annunciation device that will sound all annunciations required by the standard.</li> <li>• Verify that the UUT has an output for remote annunciation devices that will sound progress annunciation during Entry Delay and Exit Time.</li> </ul> <p>EOT</p>	<p>4.2.1</p>
<p><b>EXIT TIME</b></p>	
<p><b>VP 2 Exit Time</b></p> <ul style="list-style-type: none"> <li>• Verify that the UUT's Exit Time is defaulted (<i>for all entry/exit zones that have a unique default settings</i>) to 60 seconds.</li> <li>• Arm the UUT.</li> <li>• Verify that the time between the last arming keystroke and a Full Arm (Exit Time) is 60 seconds.</li> <li>• Disarm the UUT.</li> <li>•</li> <li>• Program the Exit Time to 45 seconds, and verify that the Exit Time is 45 seconds.</li> <li>• Program the Exit Time to 120 seconds, and verify that the Exit Time is 120 seconds.</li> <li>• Program the Exit Time to 256 seconds, and verify that the Exit Time is 255 seconds or less. (<i>Note: If the UUT did not accept programming to 256 seconds, proceed to the next test.</i>)</li> <li>• Return the UUT to the default Exit Time setting.</li> <li>• Arm the UUT.</li> <li>• Trip an entry/exit zone.</li> <li>• Verify that the time between the last arming keystroke and the local alarm is 60 seconds.</li> <li>• Disarm the UUT.</li> </ul> <p><i>If the UUT has a silent exit feature:</i></p> <ul style="list-style-type: none"> <li>• Arm the UUT with the silent feature, and verify that the Exit Time is 120 seconds.</li> <li>• Arm the UUT normally, and verify that the Exit Time is 60 seconds.</li> </ul> <p>EOT</p>	<p>4.2.2.1</p>

VALIDATION PROCEDURE	REFERENCE
<p><b>VP 3 Progress Annunciation</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT.</li> <li>• Verify that Exit Time is annunciated.</li> <li>• Verify that the annunciation changes during the last 10 seconds of the Exit Time (after 50 seconds of Exit Time.)</li> <li>• <i>If the UUT has a silent exit feature:</i></li> <li>• Arm the UUT with the silent feature</li> <li>• Verify that there is no progress annunciation during the Exit Time.</li> <li>• Disarm and rearm the UUT.</li> <li>• Verify that Exit Time is annunciated.</li> </ul> <p><b>EOT</b></p>	<p>4.2.2.2</p>
<p><b>VP 4 Exit Time Restart</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT.</li> <li>• During the Exit Time:- Trip an entry/exit zone, restore it, then trip it again.</li> <li>• Verify that the time between the second trip of the entry/exit zone and the start of the local alarm is 60 seconds.</li> <li>• Disarm the UUT.</li> <li>• Arm the UUT.</li> <li>• During the Exit Time:</li> <li>• Trip an entry/exit zone, restore it, then trip it again.</li> <li>• Then restore the entry/exit zone, and trip it again.</li> <li>• Verify that the time between the second trip of the entry/exit zone and the start of the local alarm is still 60 seconds.</li> <li>• Disarm the UUT.</li> <li>• <i>If the UUT has a silent exit feature:</i></li> <li>• Arm the UUT with the silent feature</li> <li>• During the Exit Time:</li> <li>• Trip an entry/exit zone, restore it, then trip it again.</li> <li>• Verify that the time between the second trip of the entry/exit zone and the start of the local alarm is 120 seconds.</li> </ul> <p><b>EOT</b></p>	<p>4.2.2.3</p>

VALIDATION PROCEDURE	REFERENCE
<p><b>VP 5 Exit Error</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT.</li> <li>• Violate an entry/exit zone, and leave it violated through the entire Exit Time.</li> <li>• Verify that an Exit Error sequence commences at the end of the Exit Time with the following features: <ul style="list-style-type: none"> <li>- The local alarm sounds.</li> <li>- The annunciator sounds an entry annunciation or an alarm condition.</li> <li>- An Entry Delay begins.</li> </ul> </li> <li>• Disarm the UUT prior to the expiration of the Entry Delay, and verify that no signal is sent.</li> <li>• Repeat <b>VP 5</b> without Disarming the UUT.</li> <li>• Verify that the alarm is transmitted 60 seconds after the local alarm sounds.</li> <li>• Verify that the transmission includes the appropriate alarm code and an Exit Error.</li> </ul> <p><b>EOT</b></p>	<p>4.2.2.4</p>
<p><b>VP 6 Unvacated Premises</b></p> <ul style="list-style-type: none"> <li>• Verify that the UUT is defaulted with automatic Stay Arm / unvacated premises enabled.</li> <li>• Arm the UUT.</li> <li>• Do <u>not</u> trip any entry/exit zones during the Exit Time.</li> <li>• Verify that the UUT Arms in the Stay Arm mode.</li> </ul> <p><b>EOT</b></p>	<p>4.2.2.6</p>
<p><b>VP 7 Recent Closing</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT.</li> <li>• Wait 107 seconds after the expiration of the Exit Time, then trip any non-fire, non-delayed zone.</li> <li>• Verify that a Recent Closing is transmitted along with the appropriate alarm code.</li> <li>• <i>Verify that the transmission includes the appropriate user number when available.</i></li> <li>• Disarm the UUT.</li> <li>• Arm the UUT.</li> <li>• Wait 133 seconds after the expiration of the Exit Time, then trip any non-fire, non-delayed zone.</li> <li>• Verify that the UUT does <u>not</u> send a Recent Closing transmission or a user number along with the alarm code.</li> </ul> <p><b>EOT</b></p>	<p>4.2.2.6</p>

<b>ENTRY DELAY</b>	
<b>VALIDATION PROCEDURE</b>	<b>REFERENCE</b>
<p><b>VP 8 Entry Delay</b></p> <ul style="list-style-type: none"> <li>• Verify that the UUT Entry Delay is defaulted (<i>for all entry/exit zones that have a unique default settings</i>) to 30 seconds.</li> <li>• Verify that the Abort delay is set to zero.</li> <li>• Arm the UUT, and wait for the Exit Time to expire.</li> <li>• Trip an entry/exit zone.</li> <li>• Verify that the time between the trip and the local alarm (Entry Delay) is 30 seconds.</li> <li>• Disarm the UUT.</li> <li>• Reprogram the Entry Delay to 29 seconds, and verify that the time between the trip and the local alarm is 30 seconds or greater. (<i>Note: If the UUT did not accept programming to 29 seconds , proceed to the next test.</i>)</li> <li>• Reprogram the Entry Delay to 240 seconds, and verify that the time between the trip and the local alarm is 240 seconds.</li> <li>• Disarm the UUT.</li> </ul> <p><b>EOT</b></p>	4.2.3.1
<p><b>VP 9 Progress Annunciation</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT, and wait for the Exit Time to expire.</li> <li>• Trip an entry/exit zone.</li> <li>• Verify that the UUT annunciates during the Entry Delay, and that the annunciation is different than an alarm.</li> </ul> <p><b>EOT</b></p>	4.2.3.2
<p><b>VP 10 Disarm</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT, and wait for the Exit Time to expire.</li> <li>• Trip an entry/exit zone.</li> <li>• During the Entry Delay, enter a user code.</li> <li>• Verify that Progress Annunciation is silenced on the first keystroke of the user code.</li> <li>• Verify that the system Disarms.</li> <li>• Arm the UUT, and wait for the Exit Time to expire.</li> <li>• Trip an entry/exit zone.</li> <li>• During the Entry Delay, enter an invalid user code.</li> <li>• Verify that Progress Annunciation is silenced on the first keystroke of the invalid user code.</li> <li>• Verify that Progress Annunciation resumes after the last digit of the invalid user code (<i>or after the time specified by the manufacturer</i>).</li> <li>• Verify that the Entry Delay is still 30 seconds.</li> </ul> <p><b>EOT</b></p>	4.2.3.3

<b>REMOTE CONTROL DEVICES</b>	
<b>VALIDATION PROCEDURE</b>	<b>REFERENCE</b>
<p><b>VP 11 Control Buttons and/or Remote Access Device Layout</b></p> <ul style="list-style-type: none"> <li>• Verify that the remote control device buttons are mechanically designed so that inadvertent activation is minimized. <i>(Reference the manufacturer's product literature if necessary.)</i></li> <li>• Verify that the layout of the remote access screen is designed that inadvertent activation is minimized.</li> </ul> <p><b>EOT</b></p>	<p>4.2.4.1</p> <p>4.2.4.6</p>
<p><b>VP 12 Manual Alarms (remote control device and/or remote access device)</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT.</li> <li>• Activate a manual alarm.</li> <li>• Verify that a double action trigger was used to activate the alarm. (Acceptable double action trigger activation or other safeguards/methods are typified by the examples given in clause 4.2.7 of the standard.)</li> </ul> <p><i>(This test should be repeated for all types of manual alarm activations supported by the remote control device.)</i></p> <p><b>EOT</b></p>	<p>4.2.4.2</p> <p>4.2.7</p>
<p><b>VP 13 System Acknowledgment</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT from the remote control device.</li> <li>• Verify that the UUT acknowledged the command in a manner that would normally be discernible from the exterior of the premises.</li> <li>• Disarm the UUT from the remote control device</li> <li>• Verify that the UUT acknowledged the command in a manner that would normally be discernible from the exterior of the premises.</li> </ul> <p><b>EOT</b></p>	<p>4.2.4.3</p>
<p><b>VP 14 Remote Arming</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT from the remote control device.</li> <li>• Verify that the Exit Time is 60 seconds and that Progress Annunciation occurs.</li> </ul> <p><i>If the remote control device has a silent exit feature:</i></p> <ul style="list-style-type: none"> <li>• Arm the UUT from the remote control device with the silent feature invoked</li> <li>• Verify that the Exit Time is 120 seconds.</li> <li>• Arm the UUT normally from the remote control device</li> <li>• Verify that the Exit Time is 60 seconds.</li> </ul> <p><b>EOT</b></p>	<p>4.2.4.4</p> <p>(4.2.2.1 and 4.2.2.2)</p>

<b>ALARM TRANSMISSION</b>	
<b>VALIDATION PROCEDURE</b>	<b>REFERENCE</b>
<p><b>VP 15 Abort Window</b></p> <ul style="list-style-type: none"> <li>• Verify that the UUT's Abort Window is defaulted (<i>for all non-fire zones that have a unique default settings</i>) to 30 seconds.</li> <li>• Arm the UUT, and wait till the Exit Time expires.</li> <li>• Trip a non-fire zone.</li> <li>• Verify that the time between the local alarm and the alarm signal (Abort Window) is 30 seconds.</li> <li>• Disarm the UUT.</li> <li>•</li> <li>• Reprogram the Abort Window to 15 seconds</li> <li>• Verify that the time between the local alarm and the alarm signal is 15 seconds.</li> <li>• Disarm the UUT.</li> <li>• Reprogram the Abort Window to 60 seconds, and verify that the time between the local alarm and the alarm signal is 60 seconds.</li> <li>• Disarm the UUT.</li> <li>• Reprogram the Abort Window to 60 seconds</li> <li>• (<i>Note: If the UUT did not accept programming to 61 seconds , proceed to the next test.</i>)</li> <li>• Verify that the time between the local alarm and the alarm signal is 60 seconds or less.</li> <li>• Disarm the UUT.</li> </ul> <p><i>Perform the above sequence for all non-fire zones on the UUT.</i></p> <p><b>EOT</b></p>	4.2.5.1
<p><b>VP 16 Disarm</b></p> <ul style="list-style-type: none"> <li>• Program the UUT with a User Code.</li> <li>• Arm the UUT and wait for the Exit Time to expire.</li> <li>• Trip a non-entry/exit, non-fire zone.</li> <li>• During the Abort Window, enter a user code.</li> <li>• Verify that Alarm Annunciation is silenced on the first keystroke of the user code.</li> <li>• Verify that the system Disarms.</li> <li>• Arm the UUT, and wait for the Exit Time to expire.</li> <li>• Trip an entry/exit zone.</li> <li>• During the Abort Window, enter an invalid user code.</li> <li>• Verify that Alarm Annunciation is silenced on the first keystroke of the invalid user code.</li> <li>• Verify that Alarm Annunciation resumes after the last digit of the invalid user code (<i>or after the time specified by the manufacturer</i>).</li> <li>• Verify that the Abort Window is still 30 seconds.</li> </ul> <p><b>EOT</b></p>	4.2.5.1.1



VALIDATION PROCEDURE	REFERENCE
<p><b>VP 17 Abort</b></p> <ul style="list-style-type: none"> <li>• Verify that the UUT is defaulted to annunciate that no alarm has been transmitted when the alarm is Aborted.</li> <li>• Arm the UUT, and wait for the Exit Time to expire.</li> <li>• Trip a non-fire type zone.</li> <li>• Disarm the UUT.</li> <li>• Verify that the UUT does not transmit an alarm</li> <li>• Verify that the UUT annunciates that no alarm was transmitted.</li> </ul> <p><b>EOT</b></p>	<p>4.2.5.1.2</p>
<p><b>VP 18 Alarm Transmission</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT.</li> <li>• Trip a non-fire type zone.</li> <li>• Verify that the UUT transmits the alarm no less than 30 seconds after the local alarm sounds.</li> </ul> <p><b>EOT</b></p>	<p>4.2.5.2</p>
<p><b>VP 19 Disarm</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT, and wait for the Exit Time to expire.</li> <li>• Trip a zone, and allow the system to report the alarm.</li> <li>• Disarm the UUT.</li> <li>• Verify that the UUT indicates an alarm has occurred and which zone was violated.</li> </ul> <p><b>EOT</b></p>	<p>4.2.5.3</p>
<p><b>VP 20 Cancel Window</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT, and wait for the Exit Time to expire.</li> <li>• Trip a zone, and allow the system to report the alarm.</li> <li>• Wait 4 minutes and 30 seconds after the transmission of the alarm.</li> <li>• <i>Disarm the UUT, or Disarm and depress the appropriate function key to cancel the alarm.</i></li> <li>• Verify that the UUT annunciates that a Cancel has been transmitted.</li> <li>• Verify that the UUT transmits a Cancel signal and annunciates that a Cancel was transmitted.</li> </ul> <p><b>EOT</b></p>	<p>4.2.5.4 &amp; 4.2.5.4.1 (See exception in section 4.2.5.4.1)</p>

**OTHER USER CAUSED FALSE ALARMS**

<b>VALIDATION PROCEDURE</b>	<b>REFERENCE</b>
<p><b>VP 21 Unique Duress Code</b> <i>(If duress is supported)</i></p> <ul style="list-style-type: none"><li>• Verify that the UUT duress feature is disabled as a default.</li><li>• Arm the UUT.</li><li>• Attempt to initiate a Duress alarm.</li><li>• Verify that no Duress alarm was initiated.</li><li>• Disarm the UUT.</li><li>• Reprogram the duress feature to enable it.</li><li>• Arm the UUT.</li><li>• Initiate a Duress alarm.</li><li>• Verify that a duress alarm is transmitted.</li><li>• Disarm the UUT.</li><li>• Attempt to program the duress code to match each of the other codes accepted by the UUT.</li><li>• Verify that the UUT will not accept it (either in programming or in use).</li><li>• Program the UUT with a valid duress code.</li><li>• Attempt to program a user code to match the duress code.</li><li>• Verify that the UUT will not accept it (either in programming or in use).</li></ul> <p><b>EOT</b></p>	4.2.6.1 & 4.2.6.2
<p><b>VP 22 Initiation of Manual Alarms</b></p> <ul style="list-style-type: none"><li>• Arm the UUT.</li><li>• Activate a manual alarm.</li><li>• Verify that a double action trigger was used to activate the alarm. (Acceptable double action trigger activation is typified by the examples given in Clause 4.2.7 of the standard.)</li></ul> <p><i>(This should be done for all types of manual alarm activations supported by the remote control device.)</i></p> <p><b>EOT</b></p>	4.2.7

**SECTION 2 SENSOR CAUSED FALSE ALARMS** (to be performed on each partition of the UUT)

VALIDATION PROCEDURE	REFERENCE
<p><b>VP 23 Cross Zoning</b></p> <ul style="list-style-type: none"> <li>• Verify that no zones are defaulted in a cross zoned arrangement.</li> <li>• Program two zones in a cross zoned arrangement.</li> <li>• Arm the UUT and wait until the Exit Time is expired.</li> <li>• Trip one of the zones that are programmed as a cross zone.</li> <li>• At the expiration of the cross zone time, verify that there is no local alarm and that no alarm has been transmitted.</li> <li>• <i>If the feature is available</i>, verify that an error is transmitted that reports that a trip in a cross zone was not verified.</li> <li>• Disarm and rearm the UUT.</li> <li>• Program two zones in a cross zoned arrangement.</li> <li>• Arm the UUT and wait until the Exit Time is expired.</li> <li>• Trip the other zone in the cross zoned pair.</li> <li>• At the expiration of the cross zone time, verify that there is no local alarm and that no alarm has been transmitted.</li> <li>• <i>If the feature is available</i>, verify that an error is transmitted that reports that a trip in a cross zone was not verified.</li> <li>• Disarm and rearm the UUT.</li> <li>• Program two zones in a cross zoned arrangement.</li> <li>• Arm the UUT, and wait until the Exit Time is expired.</li> <li>• Trip one of the zones that are programmed as a cross zone.</li> <li>• After the cross zone time has expired, trip the other zone in the cross zoned pair.</li> <li>• At the end of the second cross zone time, verify that there is no local alarm and that no alarm has been transmitted.</li> <li>• <i>If the feature is available</i>, verify that 2 error transmissions were made that report the unverified trips in a cross zone.</li> <li>• Disarm and rearm the UUT.</li> <li>• Program two zones in a cross zoned arrangement.</li> <li>• Arm the UUT and wait until the Exit Time is expired.</li> <li>• Trip one of the zones that are programmed as a cross zone.</li> <li>• During the cross zone time, trip the other zone in the cross zone pair.</li> <li>• Verify that the Alarm Transmission Sequence (local alarm) starts at the second trip.</li> </ul> <p><b>EOT</b></p>	<p>4.3.1</p>

VALIDATION PROCEDURE	REFERENCE
<p><b>VP 24 Swinger Shutdown</b> (Not required for fire alarms.)</p> <p>Set the system up to report both alarm and restoral reports for a zone.</p> <p>Check that the Swinger shutdown is defaulted to two trips</p> <p><b>Test for swinger shutdown after two trips</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT, and allow the Exit Time to expire.</li> <li>• Trip a zone and allow the accompanying alarm to be reported.</li> <li>• Wait for the local alarm to time out, then trip the same zone again The system shall go into alarm and the alarm shall be reported</li> <li>• Wait for the local alarm to time out, then trip the same zone a third time.</li> <li>• Verify that the system does <u>not</u> go into alarm.</li> <li>• Verify that two alarm signals were transmitted. No restoral signal should have been transmitted after the second trip.</li> <li>• Reset the system. Verify that a restoral signal is transmitted</li> </ul> <p><b>Test for swinger shutdown with the system programmed to the maximum number of trips ( Not to exceed six trips).</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT, and allow the Exit Time to expire.</li> <li>• Trip a zone and allow the accompanying alarm to be reported.</li> </ul> <p>Repeat the following step until the maximum total number of trips have occurred</p> <ul style="list-style-type: none"> <li>• Wait for the local alarm to time out, then trip the same zone again. The system shall go into alarm and the alarm shall be reported.</li> <li>• Wait for the local alarm to time out, then trip the same zone again.</li> <li>• Verify that the system does <u>not</u> go into alarm.</li> <li>• Verify that the number of alarm signals that were transmitted matches the programmed maximum. No restoral signal should have been transmitted after the last trip. Reset the system. Verify that a restoral signal is transmitted</li> </ul> <p><b>EOT</b></p>	<p>4.3.2</p>

VALIDATION PROCEDURE	REFERENCE
<p><b>VP 25 Fire Alarms</b></p> <p><b>Verify that Verification may be disabled</b></p> <ul style="list-style-type: none"> <li>• Program the UUT to disable Fire Alarm Verification.</li> <li>• Trip a sensor on a fire zone.</li> <li>• Verify that the UUT transmits an alarm signal.</li> </ul> <p><b>With Verification enabled, test that a single trip does not cause an alarm</b></p> <ul style="list-style-type: none"> <li>• Program the UUT to enable fire alarm verification.</li> <li>• Trip a sensor on a fire zone that has been configured for alarm verification.</li> <li>• For UUTs with a means for determining that a zone has been reset, verify that the UUT resets the zone. For self-resetting sensors, remove the tripping means after 5 seconds.</li> <li>• Verify that no alarm is triggered <i>within the time frame designated by the manufacturer</i>.</li> </ul> <p><b>Check that multiple trips on a sensor do trigger an alarm</b></p> <ul style="list-style-type: none"> <li>• Wait for a period of 3 minutes to allow the confirmation period to time out.</li> <li>• Trip a sensor on a fire zone that has been configured for alarm verification.</li> <li>• For a UUT with a means for determining that a zone has been reset, verify that the UUT resets the zone. When the zone is reset, trip is again <i>within the time frame designated by the manufacturer</i>. For self-resetting sensors, remove the tripping means 5 seconds after the sensor trips. Wait 15 seconds, then re-apply the tripping means and hold it.</li> <li>• Verify that an alarm signal is transmitted after the second trip <i>within the time frame designated by the manufacturer</i>.</li> </ul> <p><b>Check that a sustained trip on a sensor does trigger an alarm</b></p> <ul style="list-style-type: none"> <li>• Reset the fire alarm system of the UUT.</li> <li>• Trip a sensor on a fire zone that has been configured for alarm verification. Hold the tripping means in place.</li> <li>• Verify that an alarm signal is transmitted <i>within the time frame designated by the manufacturer</i>.</li> </ul> <p><b>EOT</b></p>	<p>4.3.3</p>

### SECTION 3 POWER CAUSED FALSE ALARMS

VALIDATION PROCEDURE	REFERENCE
<p><b>VP 26 Power Variations</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT and wait until the Exit Time is expired.</li> <li>• Vary the primary and secondary power supplied to the UUT between the <i>maximum manufacturers specifications</i> and 0 (zero).</li> <li>• Verify that no alarms are transmitted.</li> </ul> <p>EOT</p>	4.4.1
<p><b>VP 27 Labeling</b></p> <ul style="list-style-type: none"> <li>• Verify that labeling is present on the UUT interconnect label that allows an installer to confirm compatibility between the panel zone inputs and the sensors selected for the installation..</li> </ul> <p>EOT</p>	4.4.2
<p><b>VP 28 Restoration of Power</b></p> <ul style="list-style-type: none"> <li>• Arm the UUT, and wait until the Exit Time is expired.</li> <li>• Reduce the primary and secondary power to 0 (zero).</li> <li>• Restore the primary power.</li> <li>• Verify that the UUT resumes the same state of arming and bypassed zones as when power was removed.</li> <li>• Trip any sensor within 60 seconds of restoral of primary power.</li> <li>• Verify that the UUT disregards input from the sensor.</li> </ul> <p>EOT</p>	4.4.3

### SECTION 4 CALL WAITING

VALIDATION PROCEDURE	REFERENCE
<p><b>VP 29 Call Waiting</b></p> <ul style="list-style-type: none"> <li>• Program a CALL WAITING CANCEL dialing sequence.</li> </ul> <p>Note: The dial sequence for call waiting cancel is typically &lt;*70&gt;&lt;pause&gt; on a DTMF line, but may vary depending on the region of the country. To test this feature, a DTMF test set may be used to confirm that the control can dial &lt;*&gt; and all the digits on a standard DTMF phone.</p> <ul style="list-style-type: none"> <li>• Arm the UUT, and wait till the Exit Time has expired.</li> <li>• Trip any zone, and wait till an alarm transmission is started.</li> <li>• Verify, by use of a standard dial verifier, that the call waiting cancel sequence was sent before the dialed phone number.</li> <li>• When the UUT senses that a connection was not made, verify that an alternative dialing method was employed.</li> <li>• Verify that a warning to installers, not to use the call waiting cancel feature inappropriately, is provided with the UUT.</li> </ul> <p>EOT</p>	4.5

**SECTION 5 INSTALLATION AND TEST** (to be performed on each partition of the UUT)

VALIDATION PROCEDURE	REFERENCE
<p><b>VP 30 Quick Reference</b></p> <ul style="list-style-type: none"> <li>Verify that a quick reference chart or card is provided with the UUT, which details all programming locations for the features in the standard and their associated test procedures.</li> </ul> <p><b>EOT</b></p>	4.6.1
<p><b>VP 31 System Test</b></p> <ul style="list-style-type: none"> <li>Verify that the UUT has a test feature or documented test procedure which supports tests VP 32 through VP 37 below.</li> <li>When a test feature is present, verify that the test feature may be independently activated for each partition of the UUT.</li> </ul> <p><b>EOT</b></p>	4.6.2 & 4.6.3
<p><b>VP 32 Initiation of Test</b></p> <ul style="list-style-type: none"> <li>Arm the UUT and wait until the Exit Time is expired.</li> <li>Start a test sequence and verify that the UUT does not enter the test mode.</li> <li>Disarm the UUT.</li> <li>Start a test sequence, and verify that the UUT sends a transmission that a test is in progress. <i>(When the user number is available, verify that it is included in the message)</i></li> </ul> <p><b>EOT</b></p>	4.6.4.1 & 4.6.4.2
<p><b>VP 33 Communications</b></p> <ul style="list-style-type: none"> <li><i>If the UUT can be programmed to transmit information regarding system tests, verify that the setting for this feature is defaulted to disable test communications.</i></li> <li>Start a test sequence.</li> <li>Trip a zone, and verify that the UUT does not send any transmission.</li> </ul> <p><b>EOT</b></p>	4.6.5
<p><b>VP 34 Test in Progress</b></p> <ul style="list-style-type: none"> <li>Start a test sequence.</li> <li>Verify that indication of a test in progress is present at all wired system arming stations.</li> </ul> <p><b>EOT</b></p>	4.6.6
<p><b>TERMINATION OF TEST</b></p>	

VALIDATION PROCEDURE	REFERENCE
<p><b>VP 35 Automatic Termination</b></p> <p><i>If the UUT supports automatic termination of test:</i></p> <ul style="list-style-type: none"> <li>• Start a test sequence.</li> <li>• Cause the UUT to automatically terminate the test. (Refer to manufacturer's instructions.)</li> <li>• Verify that the UUT provides annunciation of an impending test termination at all wired arming stations beginning 5 minutes prior to the termination of the test.</li> <li>• Verify that the annunciation is different than that given during the test in progress.</li> </ul> <p>EOT</p>	4.6.7.1
<p><b>VP 36 State at Termination</b></p> <ul style="list-style-type: none"> <li>• Start a test sequence.</li> <li>• Terminate the test sequence, and verify that the UUT resumes operation in a Disarmed state.</li> <li>• Start a test sequence.</li> <li>• Trip a 24 hour zone.</li> <li>• Terminate the system test.</li> <li>• Verify that no alarm signal is transmitted, but that a trouble condition is indicated.</li> </ul> <p>EOT</p>	4.6.7.2
<p><b>VP 37 Termination Report</b></p> <ul style="list-style-type: none"> <li>• Start and terminate a test sequence.</li> <li>• Verify that an end of test message is transmitted.</li> </ul> <p>EOT</p>	4.6.7.3
<p><b>VP 38 Default Settings</b></p> <ul style="list-style-type: none"> <li>• Using the manufacturer's supplied installation manual, confirm that each relevant programmable feature has the default value as shown in Annex A</li> <li>• (alternative procedure)</li> <li>• Obtain a UUT configured for shipment</li> <li>• Using the UUT's built-in programming mode, confirm that each relevant programmable feature has the default value as shown in Annex A.</li> </ul> <p>EOT</p>	4.7

**SECTION 6 MOBILE OR REMOTE DEVICE TESTING** (to be performed on each partition of the UUT)

VALIDATION PROCEDURE	REFERENCE
<p><b>VP 39 Complete Alarm System Assembled</b></p> <ul style="list-style-type: none"> <li>• Verify that the UUT under validation is a complete assembly based on compliance to 4.6.1.4 Alarm System Configuration Identification</li> </ul>	4.6.1.4



<b>EOT</b>	
<p><b>VP 40 Engaging, Installing, and Enrolling the Remote “Mobile Device(s)”</b></p> <ul style="list-style-type: none"> <li>• Obtain and install the application(s) for the remote device(s). (Mobile and Non-mobile)</li> <li>• Within the security system, set the necessary parameters to support the use of a remote device(s), confirming multiple levels of user authority, if supported.</li> <li>• Take the necessary steps to enroll a remote device, ensuring enrollment is consistent with the previous parameters set up in the security system.</li> <li>• If the level of user authority for the remote device supports modifying basic data (i.e. schedules, users, delays, etc.) exercise those functions using the remote device, seeing that the correct changes are occurring within the security system.</li> <li>• If the level of user authority does not support modifying data, see that it cannot be done.</li> <li>• Ensure that actions taken via the remote device are logged and forwarded to the supervising station as would occur if the actions were performed at the security system.</li> </ul>	4.8
<p><b>VP 41 Withheld Signal – Entry delay zone – No Action taken at the remote device</b></p> <ul style="list-style-type: none"> <li>• Verify that the UUT has the “withheld “feature.</li> <li>• Only conduct these tests after successful completion of VP 8, 9, &amp; 10.</li> <li>• Verify that the UUT has the subject test zone programmed to be an “informative signal zone”</li> <li>• Obtain a “remote device” that has had the UUT’s remote application installed, verified, and enrolled in the subject UUT.</li> <li>• Verify that the UUT Entry Delay is defaulted (<i>for all entry/exit zones that have a unique default settings</i>) to 30 seconds.</li> <li>• Verify that the UUT’s Abort Window is defaulted (<i>for all non-life-safety zones that have a unique default settings</i>) to 30 seconds.</li> <li>• Arm the UUT, and wait for the Exit Time to expire and signal transmissions completed.</li> <li>• Violate an entry/exit zone.</li> <li>• Validate that the remote device is immediately sent and receives a “message” that an identified zone has been violated and is awaiting action of the remote user.</li> <li>• Do not take any action on the remote device, let the entry and abort delays expire and confirm that an appropriate alarm is transmitted to the supervision station</li> </ul>	4.8
<b>EOT</b>	
<p><b>VP 42 Withheld Signal – Entry delay zone – Withheld Action taken on the remote device</b></p> <ul style="list-style-type: none"> <li>• Verify that the UUT has the “withheld “feature.</li> <li>• Only conduct these tests after successful completion of VP 8, 9, &amp; 10.</li> <li>• Verify that the UUT has the subject test zone programmed to be an “informative signal zone”</li> <li>• Obtain a “remote device” that has had the UUT’s remote application installed verified and enrolled in the subject UUT.</li> <li>• Verify that the UUT Entry Delay is defaulted (<i>for all entry/exit zones that have a unique default settings</i>) to 30 seconds.</li> <li>• Verify that the UUT’s Abort Window is defaulted (<i>for all non-life-safety zones that have a unique default settings</i>) to 30 seconds.</li> <li>• Arm the UUT, and wait for the Exit Time to expire and signal transmissions completed.</li> <li>• Once armed and reported, violate the entry/exit zone.</li> <li>• Validate that the remote device is immediately sent and receives a “message” that an identified zone has been violated and is awaiting action of the remote user.</li> </ul>	4.8

<ul style="list-style-type: none"> <li>• During the entry delay take action on the remote device to “withhold” the alarm signal.</li> <li>• Validate that the security system logged the “withhold” event and that it was sent to the supervising station. (Identifying the affected zone, the user ID, and that it emanated from the remote device)</li> <li>• Validate that any security system sounder(s) goes silent</li> <li>• Validate that security system status remains as found.</li> <li>• Repeat the above steps, except after the expiration of the entry delay and during the abort delay take action on the remote device to “withhold” the alarm signal.</li> <li>• Validate that the security system logged the “withhold” event and that it was sent to the supervising station. (Identifying the affected zone, the user ID, and that it emanated from the remote device)</li> </ul> <p><b>EOT</b></p>	
<p><b>VP 43 Withheld Signal – Supervisory Zone.</b></p> <ul style="list-style-type: none"> <li>• Verify that the UUT has the “withheld” feature.</li> <li>• Verify that the UUT has the subject test zone, programmed to be an “informative signal zone”</li> <li>• Obtain a “remote device” that has had the UUT’s remote application installed verified and enrolled in the subject UUT.</li> <li>• Verify that the UUT’s Abort Window is defaulted (<i>for all non-life-safety zones that have a unique default settings</i>) to 30 seconds.</li> <li>• Violate the supervisory zone.</li> <li>• Validate that the remote device is immediately sent and receives a “message” that an identified zone has been violated and is awaiting action of the remote user.</li> <li>• During the abort window take action on the remote device to “withhold” the supervisory signal.</li> <li>• Validate that the security system logged the “withhold” event and that it was sent to the supervising station. (Identifying the affected zone, the user ID, and that it emanated from the remote device)</li> <li>• Validate that any security system sounder(s) goes silent</li> <li>• Repeat the above steps, but do not exercise a withhold with the remote device and validate that the original signal is sent and received at the supervising station.</li> </ul> <p><b>EOT</b></p>	
<p><b>END OF SELF VALIDATION PROCEDURE</b></p>	

## Annex E (informative) Product Marking & Listing

Here are examples of marks that are available from Underwriters Laboratories, Inc. (UL) and are issued to compliant products tested and listed in accordance with UL procedures.



NOTE: The following enhanced version of the UL mark is also an option:



### UL Listing

Since the standard requires both a local alarm and off premise transmission, UL is requiring that products they test to it be UL listed for both a local and off premises reporting. Any hardware device added to a system to meet the requirements of this standard needs to be UL listed, and UL will test to verify that a failure of this device does not compromise the existing UL requirements of the system.

## Annex F (informative) Clarifications on Effectivity

The following is being provided as informative clarifications for the effectivity of changes made to ANSI/SIA CP-01.

- F.1 "Revisions" of CP-01 will not contain changes that significantly affect the false alarm performance of the listed products
- F.2 A new "edition" of CP-01 is required when changes will significantly affect the false alarm performance of the listed products
- F.3 The Subcommittee votes on whether or not any planned update of CP-01 would be defined as a "revision"
- F.4 Effectivity for "revisions"
  - F.4.1 Effective a minimum of twelve months after the ANSI canvass process
  - F.4.2 Review of listed products (to the latest revision) is triggered if a product with modifications potentially affecting CP-01 compliance are submitted for review (See Table below)
  - F.4.3 New product submittals will be evaluated under the latest, published, CP-01 standard

<b>Re-evaluation Matrix</b>			
Item	Revision to Security system/Keypad	Re-evaluation	
		Yes	No
1	Alternate hardware construction (relay, transorb, ptc)		X
2	Alternate hardware construction (new software/firmware for new mfr. Micro-processor)	X	
3	Non CP-01 software revision (bug fixes)		X
4	Non CP-01 software revision (unrelated feature change)		X
5	CP-01 software related revision (bug fixes)	X	
6	CP-01 software related revision (feature change)	X	
7	Significant software revisions to a UL Standard (changes that would cause a full retest of Normal Operations)	X	
8	Control unit / Keypad combinations compliant with 2010		X
9	Control unit / Keypad combinations compliant with 2007		X
10	Control unit / Remote Device combinations compliant with 2019		X

- F.5 Effectivity for new "editions"
  - F.5.1 Effective a minimum of twelve months after completion of the ANSI canvass process
  - F.5.2 To continue labeling, compliant products would have to be submitted for a file review, completed before the effective date of the edition.
 

**Note:**

    - Re-evaluation to the Latest Revision of a current previous Revision compliant product will be subjected to a limited test plan based on the revisions to the validation procedure in Annex D.
    - Re-evaluation to the Latest Edition of a current 2000 Edition compliant product will be subjected to a full test plan as outlined in the validation procedure in Annex D.

## **Annex G (informative) New Central Station Signals**

This annex describes the new signals security systems will send in compliance with the SIA CP-01 false alarm reduction standard. It is divided into two categories; required and optional signals.

Note: The DC-03 and DC-05 references provided below are for information only. Please refer to the appropriate SIA Standard for the latest information.

### **I. New Signals Required by CP-01-2000**

**Exit Error** – This signal is sent if an entry/exit zone is violated at the expiration of an exit delay.

In accordance with SIA-DC-03 this signal can be one of 2 signals:

1. EA + zone ID
2. EE + User Number

When SIA-DC-05 is used, this signal is sent as:

1 + 374 + Zone ID

In addition, the following signal may also be sent:

1 + 457 + User Number

**Recent Closing** – This signal is sent if an alarm occurs within two minutes of the expiration of an exit delay.

In accordance with SIA-DC-03 this signal is sent as:

CR + User Number

When SIA-DC-05 is used, this signal is sent as:

1 + 459 + User Number

**Cancel** – This signal is sent when an alarm is canceled. Cancel is not a new signal but it is mentioned for inclusion in the Central Station Standards.

In accordance with SIA-DC-03 this signal can be one of 2 signals:

1. BC + Zone ID
2. OC + User Number

When SIA-DC-05 is used, this signal is sent as:

1 + 406 + User Number

**Start Test** – This signal is sent when the system is put into the test mode.

In accordance with SIA-DC-03 this signal is sent as:

TS

When SIA-DC-05 is used, this signal is sent as:

1+ 607 + User Number

**End Test** – This signal is sent when the system is taken out of the test mode.

In accordance with SIA-DC-03 this signal is sent as:

TE

When SIA-DC-05 is used, this signal is sent as:

3 + 607 + User Number

## II. New Signals Allowed or Recommended by CP-01-2000

**Cross Zone Error** (CP-01, Clause 4.3.1) – This optional signal is sent at the then end of a cross trip verification time if the trip was not verified by a second zone trip. The purpose is to alert the central station that a possible faulty zone exists.

In accordance with SIA-DC-03 this signal(s) may be sent as Unverified Events:

BG  
FG  
UG

When SIA-DC-05 is used, this signal is sent as:

1+ 378 + Zone ID

**Swinger Trouble** – A zone that is shut down because of a swinger has just activated again.

In accordance with SIA-DC-03 this signal is sent as:

BD + Zone ID

When SIA-DC-05 is used, this signal is sent as:

1+ 377 + Zone ID

**Swinger Trouble Restore** – A zone that is shut down because of a swinger has just restored. It is still shutdown but the state of the zone is now restored.

In accordance with SIA-DC-03 this signal is sent as:

BE + Zone ID

When SIA-DC-05 is used, this signal is sent as:

3+ 377 + Zone ID

## III. New Signals Allowed or Recommended by CP-01-2019

**Withhold** – A system user has received an “informative” signal and has chosen not to send it to the supervising station.

When SIA-DC-05-10 Digit Contact ID is used, this signal is sent as:

ACCT 58 SSSSSS 1 963 GG ZZZ C

## Annex H (informative) Common Nomenclature

This annex describes the common nomenclature for Security systems which manufacturers are encouraged to use. Because many operators, of security systems, are required to manage several panels located in multiple locations (Home, work, relatives, etc.) it is desirable that the most common functions be named alike. The following are the basic functions that may be named alike.

**Disarm** - That portion of the system that is designed to detect unauthorized entry into the protected premises is not in use. (Other forms of protection may or may not be in use).

**Cancel** - To transmit an additional alarm signal to a central station indicating that a prior signal is to be disregarded.

**Arm** - That portion of the system that is designed to detect unauthorized entry into the protected premises is in use. (Other forms of protection may or may not be in use).

**Premises Arm** - That portion of the system that is designed to detect unauthorized entry into the protected premises, when there are inhabitants within, and with the exception of the entry portal, is in use. (Other forms of protection may or may not be in use).

**No Entry Arm** - That portion of the system that is designed to detect unauthorized entry into the protected premises, when there are inhabitants within, is in use. (Other forms of protection may or may not be in use).

**Bypass** - A point of protection (window, door, etc.) is temporarily disabled from performing its intended function.

**Quick Bypass** - Upon exiting, and wishing to Arm the system, and a Point(s) is not in its intended position for Arming, the panel will allow Arming with the Point(s) disabled from performing its intended function.

**Duress** - When about to Disarm the system, the user is approached by a would-be perpetrator, and the user uses a unique function, which Disarms the system and transmits a "Duress" alarm to the monitoring center.

**Police Emergency** - A user of the alarm system has observed a situation that requires police response, and activates a unique function, which transmits a Police Emergency alarm to the monitoring center.

**Fire Emergency** - A user of the alarm system has observed a situation that requires fire department response, and activates a unique function, which transmits a Fire alarm to the monitoring center.

**Medical Emergency** - A user of the alarm system has observed a situation that requires emergency medial assistance, and activates a unique function, which transmits a Medical Emergency alarm to the monitoring center.

**Quick Arming** - An abbreviated or shorten function that Arms the system. (See Arm)

**Monitor Mode** - The system in not Armed, and any time a perimeter point of protection is activated, the security system emits a sound.

**Informative Zone/Signal** - a zone(s) that the subscriber has chosen, to be informed when it is tripped, sent immediately to a selected mobile device, whereby the subscriber will "decide" what further action is to be taken.

**Withheld and Withhold** - an action, initiated by a user that has decided an, informative signal, will not be transmitted to the supervising station.

## **Annex I (informative) System Configuration Identification (Ref. 4.6.1.1)**

Section 4.6.1.1 requires the manufacturer to identify the minimum equipment requirements for a compliant installation. It does not imply that each component in the system must be listed as CP-01 compliant. For example, consider a manufacturer that offers two types of keypads or mobile apps. First, they offer a "3100 series" of LED keypads or mobile device apps that do not support all CP-01 requirements. Second, they offer a "4100 series" of keypads or mobile device apps that has been listed and does meet support all CP-01 requirements. The manufacturer must identify that a "4100 series" keypad or mobile app must be installed for CP-01 compliance, but this does not prevent the additional use of "3100 series" keypads or mobile app in that same system.



## **Annex J (informative) Labeling (Ref. 4.4.2)**

Sensor and wiring requirements must be described so that sensor compatibility with the zone input characteristics of the panel is assured over the full range of operating conditions. Different zone types may require different compatibility specifications, but here is a hypothetical example for a hardwire supervised input:

**Zone Input Specifications:**

- maximum loop current (shorted loop): 7.4 mA
- maximum loop voltage (open loop): 5.0 VDC
- loop shorted: 0V - 0.75V (0 - 120 ohms total loop resistance)
- loop normal: 1.1V - 4.1V (190 - 3000 ohms)
- loop open: 4.6V - 5.0V (7800 - infinite ohms)

When a panel has more than one type of zone input, a specification may be required for each type.

## **Annex K**

### **(Informative)**

### **Section 4.5**

#### **Call Waiting**

To help prevent a call waiting line from interfering with the alarm verification process (causing the indication of a continuous ring when the phone line is actually in use), a programmable option for call waiting cancel shall be required on communicator/communications that use media (e.g. PSTN) where call-waiting may be provisioned. The default setting for this option shall be that it is disabled.

Should a connection not be established on the initial attempt, an alternate dialing method that does not transmit the dialing sequence to disable call waiting shall be provided to assure that the connection failure was not due to the use of the call waiting cancel feature on a non- call waiting line.

A caution shall be included with the panel alerting the installer that a call waiting cancel on a non- call-waiting line will prevent successful connection to the central station.